


BINDER FOOT

for 9 mm stitch width sewing machines

ref: 202-099-204

The binder foot makes it easy to attach pre-folded bias binding tape or bias tape you have made yourself, onto any project. Equipped with a small funnel to fold and guide the binding over the fabric edge before it reaches the needle, the binder foot can be used with either zigzag or decorative stitches as well as straight stitch



⚠ Caution

Make sure to press the Lockout key when replacing the foot and attaching the binder.

For models without the Lockout key, turn the power switch off when attaching and detaching the foot and binder.

Please refer to your machine's instruction manual for accessory attachment and removal information.

Machine Settings:


Stitch pattern: Straight stitch
(center needle position)

To Sew:

Cut the end of the binding tape diagonally and insert it into the funnel. Pull out the tape end and draw it toward the rear under the foot.

*You may use a needle or stiletto to draw the tape through the funnel.

Insert fabric edge into the slit of the funnel and between the tape. Sew slowly while guiding the tape and fabric into the funnel.



PIED POUR POSE DE BIAIS

pour machines à coudre avec 9 mm

de largeur de couture Réf: 202-099-204

Ce dispositif convient à des biais très larges et plie ces derniers à une largeur finale de 15 mm (1/2"). Cet accessoire peut être utilisé avec le double transport sur une machine à coudre avec un mécanisme de double transport.

⚠ Attention

Appuyez sur le bouton de verrouillage lorsque vous remplacez le pied et fixez le dispositif.

Pour les modèles de machines sans bouton de verrouillage, coupez le contact lorsque vous retirez ou fixez un accessoire.

Référez-vous au manuel d'instructions de votre machine à coudre pour toutes les informations concernant la fixation et le changement d'un accessoire.

Réglages de la machine:

Motif du point: point droit
(position de l'aiguille au centre)

Pour coudre:

Coupez l'extrémité du biais en diagonale et insérez-la dans la spirale. Tirez l'extrémité du biais vers l'arrière jusqu'à ce que ce dernier soit placé sous le pied.

* Vous pouvez utiliser une aiguille ou un stylet pour passer le biais dans la spirale.

Insérez le bord du tissu dans la fente de la spirale et entre le biais. Cousez doucement en guidant le biais et le tissu dans la spirale.