

DITCH QUILTING FOOT

for 9 mm stitch width sewing machines

ref: 202-087-209

Use this foot for perfect placement when stitching in the ditch. The guide on the foot can also be used when adding top stitching along seams.




⚠ Caution

Make sure to press the Lockout key when replacing the foot or attaching a binder.

For models without the Lockout key, turn the power switch off when attaching and detaching the foot and binder.


Please refer to your machine's instruction manual for accessory attachment and removal information.

Machine Settings:

Stitch pattern: Straight stitch 
(center needle position)

To Sew:

Set the folded edge along the presser foot guide and sew with a straight stitch.



PIED AVEC GUIDE CENTRAL

pour machines à coudre avec 9 mm

de largeur de couture Réf: 202-087-209

Ce pied avec un guide central vous permet de réaliser une piqûre ou une surpiqûre avec une très grande précision.

⚠ Attention

Appuyez sur le bouton de verrouillage lorsque vous remplacez le pied ou fixez un dispositif.

Pour les modèles de machines sans bouton de verrouillage, coupez le contact lorsque vous retirez ou fixez un accessoire.

Référez-vous au manuel d'instructions de votre machine à coudre pour toutes les informations concernant le fixation et le changement d'un accessoire.

Réglages de la machine:

Motif du point: point droit 
(position de l'aiguille au centre)

Pour coudre:

Posez le bord plié le long du guide et cousez avec un point droit.